

How to Order Replacement Hubs or Hub and Drums

To order the correct replacement hub or hub and drum, the following steps can be used to simplify the ordering process:

- 1. Determine the Bolt Pattern of the Hub.**
Refer to page E-6 of this catalog for instructions on making this determination.
- 2. Determine the Inner and Outer Bearing Numbers. Note whether the bearings use grease or oil bath lubrication.**
- 3. Measure the old hub seal to insure that the I.D. and O.D. dimensions will be the same.**
- 4. Verify the Stud Diameter.**
- 5. If the axle is a brake axle, measure the diameter and width of the brake to determine brake size.**
- 6. Look for any casting numbers on front or rear of hub or hub and drum.**
- 7. On heavier axles, such as the Dexter 8,000 lb. or 9,000 lb. axles, you need to determine the hub pilot diameter. This can be accomplished by measuring the center hole of your wheel.**
- 8. On 8,000 lb and larger axles determine if it is equipped with ABS, and requires a drum / rotor with ABS exciter ring installed.**

Once you have the above information, you are ready to locate your replacement hub or hub and drum. Hubs are listed on pages B-12 thru B-17. Hub and drums are listed on pages B-18 thru B-34.

Locate the bolt pattern desired, then find the table that lists our inner and outer bearing numbers. Verify:

Inner/Outer Bearing Numbers
Type of Bearing Lubrication
Stud Size
Seal Size
Drum Size

Confirm brake size and/or hub pilot diameter (if applicable). Complete assemblies contain the hub or hub and drum, inner and outer bearings, seal, grease cap or oil cap and all necessary wheel nuts.



Hubs are Shown on Pages B-12 thru B-17
Hub and Drums are Shown on Pages B-18 thru B-34